



***Color-Paste UV
100% Pigment Dispersion***

***for solvent-free
UV-Coatings***

Color-Paste UV - for radiation-curing systems

This product line has been specifically designed to cover a wide range of possibilities for application in radiation-curing systems. The use of a bifunctional reactive diluent as a dispersion medium ensures a wide compatibility and low viscosity of the color pastes. An excellent compatibility in commercially available binders such as urethane, polyether and epoxy acrylates is given.

Possibilities for application as follows:

- **Adhesives**
- **Ink Jet**
- **Foils**
- **Parquet oils**
- **Process colours**
- **Gelcoats**
- **Wood stains**
- **Printing inks**
- **Can-Coatings**

The used pigments were chosen for their very high transparency. Lightfast and chemical-resistant pigments are deployed. The color pastes contain no photoinitiators and show an excellent storage stability. The products are easy to incorporate, free flowing and pumpable.

PurpurLab GmbH

Your partner for best colour quality!

www.purpurlab.com · Contact: +49 (0) 24 21 / 99 00 89 10